




USER MANUAL

CORONA CAMERA

UV-260





USER MANUAL

CORONA CAMERA UV-260



**SONEL S.A.
Wokulskiego 11
58-100 Świdnica**

Version 1.04 13.10.2020

The UV-260 Corona Camera detects and precisely locates corona discharge emanating from high-voltage devices. It will help locate and determine the power of a discharge by capturing UV radiation released during corona discharge and provides a reliable method for the technical assessment of the operation and behaviour of high-voltage equipment.

When corona discharges are detected, the camera will overlay images of the corona on the visible image. Images are displayed in real time on the camera's screen. Under user control the images may be also recorded as a video file. Images may be stopped and saved as a still image. Recorded images and videos are stored on a removable SD card in a format compatible with viewing on personal computers.

Main features of UV-260:

- high UV-sensitivity, user adjustable
- automatic or manual focus adjustment for real image and UV image
- combining of visible-spectrum images and UV-spectrum images
- automatic reduction of noise and interference
- 5.7" TFT touch-screen
- designed to operate in sunlight
- UV discharge detection alarm
- built-in GPS system for recording location
- precisely locates UV discharge sources
- UV discharges and visible images recorded as photos or videos in common PC format
- report generator program included

CONTENTS

1. Introduction	5
2. Safety	5
3. Principle of Operation	6
3.1. Electromagnetic radiation: visible, infra-red, ultraviolet.....	6
3.2. Mechanism of Corona Discharge.....	7
3.3. Why Corona Discharge?.....	8
3.4. Detection of Corona Discharge.....	8
4. Preparing the Camera for Operation	10
4.1. External design of the camera.....	10
4.2. Mounting on a Tripod.....	11
4.3. Moving and Holding the Camera.....	12
5. Ports and Buttons	13
5.1. External Ports.....	13
5.2. Layout and functions of buttons.....	14
5.2.1. Navigation buttons.....	14
5.2.2. Operating mode buttons.....	15
5.2.3. Control of power supply / charging and alarm - corona discharge indicator.....	15
6. Operation and Battery Charging	15
6.1. Inserting the Battery.....	15
6.2. Charging the Battery.....	16
6.3. Guidelines for Using the Battery.....	16
7. Working with UV-260 Camera	17
7.1. Operation of the buttons.....	18
7.1.1. Recording a Video.....	18
7.1.2. Recording a Static image.....	18
7.1.3. Switching the Image Mode.....	18
7.1.4. "Freezing" Displayed Image.....	18
7.1.5. Changing the Focus Mode.....	18
7.1.6. Gain Adjustment.....	19
7.1.7. Zoom.....	19
7.1.8. Manual Focus.....	19
7.1.9. Zooming In.....	19
7.1.10. Playing a Voice Note.....	19
7.1.11. Zooming UV+ Image.....	19
7.2. Operating the Menu.....	20
7.2.1. Main menu.....	20
7.2.2. Image Settings.....	21
7.2.3. Video.....	22
7.2.4. Image.....	22
7.2.5. System.....	22
7.2.6. Sub-menu "System Settings".....	23
8. "Sonel UV Analyse" software	24
8.1. System Requirements.....	24
8.2. Software Operation.....	24

8.2.1.	Starting-up Software.....	24
8.3.	Software Operation.....	25
8.3.1.	Main Function Area.....	25
8.3.2.	Toolbar.....	26
8.3.3.	Template Selection.....	26
8.3.4.	Appearance Setting & Font Setting.....	28
8.3.5.	Cancel.....	28
8.3.6.	Line.....	28
8.3.7.	Edit Box.....	28
8.3.8.	Add Pictures.....	28
8.3.9.	Image Setup.....	30
8.3.10.	Audio Play.....	31
8.3.11.	List box.....	32
8.3.12.	Vertical list.....	33
8.3.13.	Line Analysis.....	33
8.3.14.	Histogram.....	34
8.3.15.	Page Attribute.....	35
8.3.16.	Video Transmission.....	35
10.	Other Information	38
10.1.	Cleaning and Maintenance	38
10.2.	Storage	38
10.3.	Dismantling and Disposal.....	38
10.4.	Transport.....	38
11.	Technical specifications	39
12.	Accessories.....	40
13.	Manufacturer	41

1. Introduction

Thank you for choosing the UV-260 corona camera. The UV-260 Corona Camera is a high-quality imaging device that is easy and safe to use. Carefully read this manual before the first use to prevent errors and problems while operating the device.

This manual contains three types of warnings that describe the possible risks both for the user and the device. Information with a "WARNING" describe situations which may endanger the user's life or health when instructions are not followed. "CAUTION!" describes of a situation which may result in damage to the device when instructions are not followed. Indication of possible problems is preceded by "Note".

The device has been designed, developed, and manufactured in accordance with ISO 9001 quality systems. Sonel reserves the right to change device specifications without prior notice. Copyright of this manual and software are the property of Sonel.

2. Safety

WARNING

Do not attempt to open the device as none of the components can be repaired or calibrated by the user. Any maintenance activities may be carried out only by authorized service personnel.

NOTE

Do not drop, or subject the camera to rough handling or shocks during operation, handling, and transportation.

NOTE

Avoid pointing the lens directly at the sun or objects that emit very high temperature as this may cause damage. Take care to observe this precaution and make sure the camera is not pointed at the sun when switching the device ON/OFF.

NOTE

Never touch the lens. Dust accumulated on the lens may be removed only by using special tools or compressed clean air.

The camera should be stored in cool, dry place, away from sources of strong electromagnetic fields. When the camera is not used for a long time remove the batteries.

During operation the camera should be securely fastened to minimize shake and vibrations that will adversely affect the accuracy.

WARNING

Do not use the camera if it's enclosure is damaged in any way as this is a safety threat to the user.

When working with the device observe the technical conditions specified in this manual.

Damage to the camera, resulting from improper use, alteration, and obvious negligence are not covered by the warrantee.

3. Principle of Operation

Corona discharge is one of three types of partial discharge. Partial discharge is the breakdown of an insulator (or dielectric) caused by high voltage stress, usually in a portion or area between two conductors that does not result in a complete short circuit. In addition to corona discharge there are surface discharges, due to contaminated insulator surfaces, and internal discharges caused by the degradation of the insulation that results in voids or pockets that provides paths for partial discharge to develop. These situations are progressive in that discharge currents exacerbate further degradation ultimately leading to complete insulator failure. Corona-type partial discharge is the localized ionization of a gaseous insulation system, such as air, usually confined to a limited distance between two conductors. Corona can occur within voids in insulators as well as at the surfaces where conductors and insulators meet.

3.1. Electromagnetic radiation: visible, infra-red, ultraviolet

Individual types of electromagnetic radiation have wavelengths as shown in Figure 1.




Figure 1: Electromagnetic waves of different lengths.

3.2. Mechanism of Corona Discharge

Corona discharge is a current flow, usually in a gas such as air, from a discharge electrode under high voltage conditions that causes ionization of the surrounding gas. Ionization is the separation of electrons from the gas atoms. If sufficiently ionized the gas can create a plasma; ionized matter containing electrically charged particles, around the electrode. The ions in the plasma create an electrical path that carry the electrons to lower potential.

If the discharge electrode has a sharp or pointed shape, a high-voltage potential gradient is generated around the point. If the potential gradient is high enough to cause ionization a discharge will occur. At very high voltage it may be a sparking phenomena, or it may be an arc whereby a plasma is created that establishes a path of continuous electron flow. Corona accompanies plasma states but also occurs when ionization levels are not at a full plasma state of high volume electron flow; i.e. corona emissions can also be initiated a lower level of discharge or electron flow provided ionization is present.

Most corona discharge is invisible in daylight. Even in total darkness it may be barely visible as a blue-violet afterglow as most of the radiation generated is in the ultraviolet range and invisible to human eye. Attempting to observe corona at night is virtually impossible since total darkness cannot be achieved in urban environments. Other methods of detection attempts to use acoustics to detect the crackling sounds that can accompany discharges but these methods are unreliable and cannot precisely locate the source of corona generation. Thus, acoustic-based detection methods are being replaced with UV-based detectors that are far more effective.

Corona discharges are generated in the electromagnetic spectrum wavelengths in the range between 200 to 405 nm. Solar radiation contains visible light, infra-red, and ultraviolet radiation. By using an appropriate filter with wavelength between 240 to 280 nm to suppress UV radiation from the sun the camera is designed to detect corona even in daylight conditions.




Fig. 2: The spectrum of corona discharge

Depending on the polarity of the discharge electrode, the corona discharge may be positive or negative. In either case of negative or positive discharges photons are the main source of radiation. When the gas atoms are ionized their electrons are "excited" and kicked up to a higher energy states. Photons are released by the ionized atoms as they return to lower energy states. The corona camera shows a display scale in "UV photons" to provide an indication of the volume of photons generated.

Positive discharge is said to be homogeneous; the majority of charges are concentrated close to the electrode so the discharge area is well defined and easily located. Negative discharge at the same voltage may be weaker and more difficult to locate since the energy is more spread out over a wider area.

3.3. Why Corona Discharge?

Corona discharges are a loss of energy. Unwanted corona discharge also cause a variety of problems such as radio interference i.e. poor reception of radio signals due to noise coming from nearby high voltage power lines. The most adverse effect of corona discharges is the impact on the condition of insulation elements resulting in "wear and tear" over time; i.e. the gradual deterioration of the insulator and it's ability of the to provide a dielectric barrier. Even the presence of small discharges cause adverse effects. The discharge current flow generates corrosive substances that contribute to the breakdown of insulators creating voids and cracks. These enable the ingress of moisture to internal components, further accelerating degradation.

If left unchecked bad insulation can bring about the failure of entire power transmission systems. Since high voltage transmission systems are the main arteries of power that serve millions of consumers, any disruption to the electrical grid's transmission systems is both economically and socially disastrous. Therefore, it is prudent to detect the early stages of corona discharges to catch incipient problems before they develop and lead to permanent damage that results in costly repairs and wide-area blackouts. Locating corona discharges is a sensible cautionary preventative maintenance measure, similar to infra-red thermal camera inspection methods, to discover potential problems before they arise.

3.4. Detection of Corona Discharge

The UV-260 detects and locates corona discharges by detecting their UV radiation. The level of discharge is quantified and the number of discharges in a certain time-frame is represented graphically by the 'UV image'. The camera operates in both the visible light and the UV spectrums. By pointing the camera at a desired object and viewing it as a real image, in the same way as any video camera, any detected UV emissions are precisely overlaid on the visible image. The UV radiation is represented as a white, blue, or red video image rendered against the visible image. This provides an accurate method of locating the source of emissions and therefore the point of degradation that would otherwise be difficult to distinguish in high voltage transmission systems, or complex substations with multiple conductors and equipment. Inspection for corona with the UV-260 is inherently safe when high voltage systems are live since inspection is performed from a distance.




Fig. 3, 4. Corona discharge in laboratory conditions.






Fig. 5-8. Corona discharge in real power grids.




Fig. 9, 10. Corona discharge and its effects.

4. Preparing the Camera for Operation

4.1. External design of the camera

The UV-260 is compact, simple, and ergonomic camera to use. It may be operated on a tripod or used as a hand-held tool. Its features are illustrated in Figures 11 and 12.



Fig. 11. Parts of Camera UV-260.

4.2. Mounting on a Tripod

For long periods of observation mounting the camera on a tripod is recommended to eliminate shake and vibration (Fig. 12). A standard, threaded tripod mount is provided at the bottom of the camera.

Note. Firmly attach the camera to the tripod to prevent accidental damage.



Fig. 12 UV-260 mounted on a tripod.

4.3. Moving and Holding the Camera

The UV-260 may be used as a hand-held device, or the operator can use the more convenient strap to ease fatigue from holding for long periods. The strap also frees the operator's hands during operation (Fig. 13, 14).

CAUTION!

To prevent dropping and damaging the camera when fastening and unfastening of the strap place the camera on a table or other surface, and fasten or unfasten the strap in the upright position (fig. 13). Test the strap is securely fastened before operation.



Fig. 13. Fixing strap to the holders.

The camera when suspended on the strap allows the operator to easily use the keyboard (Figure 14).



Fig. 14. The camera securely mounted on the strap.

5. Ports and Buttons

5.1. External Ports

Camera interfaces, charging indicator, power adapter input, SD card slot, and the battery compartment are located under the cover on the side of the camera (Fig. 15).




Fig. 15. Arrangement of ports under the cover.

Video output may operate in PAL or NTSC system.

The SD card must be formatted in FAT32.

When recording voice notes speak closely into the microphone. Plug the microphone headset into the audio input located under the cover.

CAUTION!

When inserting the battery pay attention to the correct polarity.

Voltage connected to power input cannot exceed 12V.

5.2. Layout and functions of buttons



Fig. 16. Arrangement of the control panel buttons.

5.2.1. Navigation buttons

Buttons for menu operation and image functions:



- Up,



- Down,



- Left,



- Right,



- confirm,



- exit without confirmation.

In addition to menu navigation, functions of the buttons are as follows:



- "freezing" the displayed image,



- switching into the focus adjustment mode,



- playing a voice note



- zooming in combined (mixed) image mode (real image +UV).

5.2.2. Operating mode buttons



- image display mode switch, repeated pressing of the button causes toggling of the following modes: UV image only - visible image mode - mixed mode (UV plus visible image)



- saving the still image,



- video recording,



and - manual focus adjustment,



and - zoom in/out

5.2.3. Control of power supply / charging and alarm - corona discharge indicator



- switching on / off,



- power indicator,



- corona discharge indicator.

6. Operation and Battery Charging

The UV-260 is powered by a dedicated lithium-ion rechargeable battery, which should be charged only with the charger included with the camera. Any other batteries, even of the same shape, and other chargers may damage the camera and present a danger to the user.

The battery may be also charged by the camera via an AC adapter or a car adapter (12V) - both included with the camera.

When battery level is low a message will be displayed on the screen indicating the need for recharging.

6.1. Inserting the Battery

Insert the battery into the battery compartment located under the cover for inputs and battery compartment (Fig. 15).

6.2. *Charging the Battery*

The battery may be charged using the external charger or by connecting the AC adapter with the battery inserted into the camera using the power socket located slot under the battery compartment cover [4](#).

The charging indicator light is red during charging. When charging is completed the charging indicator light is green.

WARNING.

At high temperatures do not turn on the camera while charging the battery, as it may decrease battery life, or even cause fire.

6.3. *Guidelines for Using the Battery*

Charge the batteries in a dry indoor location. Do not charge the batteries outside, especially during rain, etc.


WARNING.

Do not short-circuit the battery, and avoid accidental short circuits by preventing the battery terminals from coming into contact with other metal, or loose objects.

The battery should be stored at a temperature not exceeding 60°C / 140°F.

When charging is finished disconnect the external power supply adapter. When replacing the battery disconnect the power supply adapter first. Insert the battery into the camera, and then connect the AC adapter. Do not use non-original batteries and chargers.

7. Working with UV-260 Camera

In order to switch the camera on press and hold  button for approx. 2 seconds. The camera starts by performing auto-tests for about 25 seconds, then it switches on the operating screen (Figure 17).




Fig. 17. Working screen in mixed image mode - detecting corona discharges.

The screen, in addition to the image in the selected mode (UV, visible, mixed), displays the following information:


- current date and time,
- GPS coordinates of the measurement location
- signal gain level
- battery charge status
- focus adjustment mode (auto or manual),
- image mode indicator: mixed **UV+**, visible image **VIS**, or UV image only: **UV**

The white frame is the effective area for photon counting, where discharges are recorded and the amount of UV photons indicated. The operator may select 3 frame sizes - large, medium, and small.

7.1. Operation of the buttons



Description of the operations available by pressing buttons in the working screen mode.

7.1.1. Recording a Video

Press  to start recording a video and saving it on a SD card. This allows real-time recording of images that are displayed on the screen. When recording video you may add a voice note using the headset connected the audio input. Video files are recorded in "avi" format that can be played in the camera or on a PC.





7.1.2. Recording a Static image

Press  to save the image displayed on the screen into the SD card.


When the image is recorded the screen displays the message "record a voice note". At this point you can record 20-second voice memo, press  to start voice recording (with a microphone headset connected to the audio input). The image is saved and the camera returns to the real-time mode. Or press  to save the image without recording a voice note.



Note. For the best quality it is recommended to 'freeze' the image on the screen before saving it - see below.

7.1.3. Switching the Image Mode


Use  button to toggle and switch between the following modes: Visual image only () , UV discharge mode only () and Mixed mode () .

7.1.4. "Freezing" Displayed Image



Pressing  "freezes" the image allowing you to make a decision about saving it into memory. At this point:

- press  to save image to the SD card and return to detection mode in real-time
- press  again to return to the detection mode (real-time) without saving the image.



7.1.5. Changing the Focus Mode

Press  to change the focus mode from manual to automatic and vice versa. By default, the camera upon powering on is set to auto focus mode. In case of a complex image with many objects at different distances the focus may not be set automatically to the desired object. If so the operator can switch to the manual focus mode.

7.1.6. Gain Adjustment

In **[UV]** image mode or in mixed mode (**[UV+]**) buttons  and  are used to increase or decrease the sensitivity of the camera UV detector. Increasing the sensitivity results in displaying both high and very low discharges, and may display unwanted UV interference. Decreasing the sensitivity allows the operator to observe only high-power discharges, and more precisely locate their sources.







7.1.7. Zoom

In the visual image mode, use buttons  and  to zoom in/out the image by reducing or increasing the camera angle of view.


7.1.8. Manual Focus

In manual focus mode (see 7.1.5), use buttons  and  to manually adjust the focus of the image.


7.1.9. Zooming In

In the image preview mode, press  to zoom the image by 2x or 4x. When the image is enlarged, use buttons , , ,  to navigate through the image. Press  to enter the real-time image mode.



7.1.10. Playing a Voice Note

When the image was saved with a voice note it may be played in the image preview mode by pressing . Use a headset connected to the audio input to listen to voice notes.

7.1.11. Zooming **[UV+]** Image





In Mixed image mode **[UV+]** and in UV mode **[UV]**, press  to enlarge (zoom) the image by 1x or 2x. This makes it easier to precisely locate the source of UV emissions and the most probable location of physical damage or deterioration of the observed object by finding where the most UV emissions are originating from.

7.2. Operating the Menu

The UV-260 does not display the menu on startup. Enter the main menu by pressing  in the real-time image mode or by touching any place on the touch-screen. Press  or touch the screen where the menu is not displayed to close the menu.

Note. Menu options are simple and intuitive. All operations in the menu are performed by touching the individual items on the screen in drop-down menu sections, or by navigating through the menu using the cursor keys.

7.2.1. Main menu

With any opened drop-down menu, select the desired option by touching where it is displayed, or move the highlighted area in the menu with cursor keys  or , then confirm the selection by pressing . At any stage you may press  to exit the menu.




Fig. 18. Main menu.

7.2.2. Image Settings




Fig. 19. Menu – Image Settings.






The "Image Settings" menu allows you to alter how UV images are displayed. Specific options are presented below. Select/change options in the same way as in the main menu (use "arrow" key and confirm by pressing , exit to the previous menu by ; or touch selected area of the screen).

Image mode: function is analogous to pressing button , selecting between Visible image, UV image and Mixed image.

UV image color: select colour for displaying UV discharges (available colours: red, white and blue).

Photon counting interval: Set the interval time for photon counting, There are 10 time intervals of 1s, 2s, 3s, 4s, 5s, 6s, 7s, 8s, 9s, 10s.

Integral duration - integration time length: Set the integration duration, which can be set to 1, 2, 4, 8, 16 and 32. The integration function is used to accumulate the UV signal to filter out the random interference. Within the selected integration time, the discharge point appears repeatedly in the same place and is accumulated into larger signal, while the random interference signal will not be accumulated into a large signal, when the gain is reduced, the random interference will be filtered.

Gain: adjusts the sensitivity of UV detector (similarly - use buttons  and  in UV image mode UV or mixed mode UV+) to increase or decrease.

Note. Setting high gain allows you to capture weak UV signals and detect very small discharges, but it should be remembered that high gain may affect the accuracy of locating discharge sources. This is because as the UV image will cover a larger area of the visible image making it difficult to determine the exact location. All UV radiation from both the actual discharge source, as well as unwanted, interfering sources will be detected. The unwanted detection usually appears scattered and in random positions.

A good technique is to first set a high gain level to roughly determine the discharge location, and then gradually reduce the gain to a level that will show the precise location of discharges.

For relatively large interferences extend the averaging time and simultaneously reduce the gain level to eliminate background noise and better pinpoint the sources of corona discharges.

UV overlay transparency: sets the transparency of UV image overlaid onto the real image (0% - opaque, 50% - translucent)

Photon counting box: selects the area where discharges are counted. The frame can be set in 3 sizes: large, medium, and small.

Brightness: sets the brightness level of the screen, depending on external conditions.

Exit: return to the main menu.

7.2.3. Video

Provides functions for video files saved on the SD card: i.e. view, delete files, and view detailed information about recorded video files. File names correspond to their dates of creation.

7.2.4. Image

For viewing or deleting images saved on the SD card. While viewing images the operator can zoom in and play a voice note if previously recorded. Image file names correspond to the dates of their creation. The images are displayed in the form of a list or thumbnails.

7.2.5. System

After selecting "System" option a sub-menu is displayed where the user may change system settings to change:

- time settings
- factory settings
- formatting the SD card
- displaying information about the SD card
- displaying information about the camera




Fig. 20. System menu.

7.2.6. Sub-menu "System Settings"




Fig. 21. "System Settings" Menu.

Language: selects the interface language.

Monitor: selects the video standard (PAL or NTSC) for the camera display screen.

Auto shutdown: sets the camera to automatically turn-off when no button is pressed for a set time.

UV alarm: turns the audible alarm, after detecting UV discharges, On or Off.

Photon threshold: sets the level of corona discharge (the amount of recorded photons) to trigger the alarm.

GPS: Turn GPS function on or off.

USB: There are two modes: video and file transmission.

- ① Video: Video needs to be used with Report software. In the device system settings, select video in USB. After the device is connected to the computer, open the video management button installed in theReport software on the computer, click the search button, search the device and then play it.
- ② File transmission: Select file transfer. After the device is connected to the computer, a removable storage device will appear on the computer. Double click to open it and select the required file or picture.

Focus mode: selects manual or auto focus (the same as pressing  button).

File name display: Set the display duration of file name from available: 1s, 2s, 3s, 4s, 5s.

8. "Sonel UV Analyse" software

8.1. System Requirements

Due to the large size of video files, you must provide enough disk space on your computer and meet the following requirements:

- CPU 2.0GHz processor or faster;
- 2Gbytes or more system memory;
- 80G or bigger hard disk;
- 1440×900 or higher resolution screen (Suggestion).

The software runs under Microsoft Windows 2000, XP, Vista and Windows 7.

8.2. Software Operation

8.2.1. Starting-up Software

After unzipping the software, click the software icon to open the software as shown in figure 22.




Figure 22

There will be a hint reminding users to download templates. After adding, users can also delete the template when you right-click the template name and select "Delete Template".

8.3. Software Operation

8.3.1. Main Function Area

There are five main functions in this area: File, View, Insert, Setup and Help.



Figure 23

a. File

It can save file as template or save template directly. And it can output words, manage files and videos, as well as batch export gray images.

Batch export gray images: Firstly, users have to click “File→Batch export gray image analysis”. Secondly, select the templates and documents you need. And then click “output Word” to export gray images. If there are some documents that users don’t need, you can click the “Delete” to delete them. As shown in the figure 24.




Figure 24

b. View

In this part, there is “Toolbar and Window” which can show or hide the toolbar and the status bar. As shown in the figure 25.



Figure 25

c. Insert

In this part, users can add the lines, edit boxes, original pictures, line analyses, picture boxes, LOGOs, list boxes and vertical lists. Besides, users can add or delete pages, as well as flip pages.

d. Setup

In this part, users can set up the temperature and add grid.




Figure 26

e. Help

In this part, users can look through the user manual of software when you click the “Doc”; get the information of the version when you click the “About”; and change the language when users click the “Language”.

8.3.2. Toolbar

It includes all tools to edit report. Users can use the tools according to needs.





Figure 27

8.3.3. Template Selection

When users edit the report, there are several kinds of templates you can choose, blank

template, IR template, UV template, and Gas template. Click  in the left side to load template you need.

a. Blank Template

When you choose the blank template, the edit area is blank and users can add things you needed.

b. IR Template

This template is compatible with the first-hand pictures shot by IR devices. Users can download templates by themselves. The edit area is setup already in order to save your time, but users can still add or delete things.

Infrared Detect Report

Rransformer Substation	XXX	Weather	XXX
Device Name ,Position	XXX	Device History Max Current(A)	1540
Rating Current(A)	3150	Load Current(A)	1435
GPS N		GPS E	

IR Image



Pic Info	Data
Create Date	2015-09-19
Create Time	18:30:54
MessageObject	Data
NO_1_1MaxTemp	24.31°C
NO_1_2MaxTemp	69.33°C
NO_1_3MaxTemp	22.65°C
NO_1_4MaxTemp	24.43°C
NO_1_5MaxTemp	24.31°C

Visible Image



Figure 28

c. UV Template

This template is compatible with the first-hand pictures shot by UV devices, which called UV template.


In UV template, users could look through the picture information of pictures which are shot by UV device, such as photon number, GPS, create time and so on. And users could make some records below in the template.


The edit area is setup already in order to save your time, but users can still add or delete things.

d. Gas Template

This template is compatible with the first-hand pictures shot in gas mode.

8.3.4. Appearance Setting & Font Setting

This area is the shown area by default. If users want to hide it, you have to click the left button of . According to your needs, you can set up the way of alignment, frame color and back color when you select a picture, a text box, a list box or a vertical list. Besides, you can set up the front, such as size, bold, colour and so on. As shown in figure 29.

Click  to hide all the menu bars on the left, including template selection, appearance settings and font settings.




Figure 29

8.3.5. Cancel

When you click the tool in the toolbar unintentionally, users can click "Cancel" to cancel operation.

8.3.6. Line

Click "Line" if users want add horizontal lines, vertical lines or black boxes.

8.3.7. Edit Box

Users can add edit boxes to take down notes.

8.3.8. Add Pictures

a. Original Picture

Select "Original Picture" in the toolbar, and then add the picture box to the ideal position, as shown in figure 30 and 31. (The box in figure 30 is unchecked so that it can't add picture. You need to select it with your left mouse button clicking, so that you can add a picture, as shown in figure 31.)

Select "File Manage" in the toolbar. When the menu bar appears, please double click the left mouse button to add pictures, as shown in figure 32. (Take the thermal image as example.)

Attention: The pictures in this part should be the first-hand pictures shot by IR or UV device, not including the visible images.

For images shot by IR device, users can set up the image attributes and play audios as clicking the right mouse button. For images shot by UV device, users can set up the image attributes as well. But the audio play function is not available for UV images. See also sec. 8.3.9 and 8.3.10.




Figure 30



Figure 31



Figure 32

b. Picture Box

This function is compatible with the “Original Picture”. This function works only if there is a picture in the original picture box. By default, the box will show the visible picture of NO.1 original picture. Users can set up the property, original object number and device number in the menu bar, as shown in figure 33.




Figure 33

c. LOGO

Select "LOGO" in the toolbar, and then add the picture box to the ideal position. Click the right mouse button and select

"Change LOGO" to add picture. In this function, any JPG/JPEG files could be added.

d. UltraMax Picture

It is not available for the device without ultramax function.


Please turn on the UltraMax of device and take pictures before using this function.

Select "Original Picture" in the toolbar, and then add the picture box to the ideal position. Click the right mouse button and select "File Manage" in the toolbar. When the menu bar pops up, please select the ultramax picture, click the right mouse button and select "Ultrapix Picture", as shown in figure 34.

In this function, the picture will be much more clearer and the temperature analysis will be much more accurate.



Figure 34

In Icon mode, the unchecked ultramax pictures are highlighted by yellow background, and the checked ultramax pictures are highlighted by blue background. In list mode, the ultramax pictures are distinguished by the mark .

Click the right mouse button, and users can set up the attributes and temperature range, as well as play videos.

8.3.9. Image Setup

a. IR Non-gas Image

After adding pictures, please click right mouse button and select "Attribute settings". The menu bar pops up, as shown in Picture 35.

- The image setup is on the left, and the temperature range is on the right. Users can adjust the temperature setup range automatically or manually. In addition, users can add points, lines, regions, ellipse or polygon to the pictures, one at a time. And users can also delete one of them, delete all information, or initialize the adding operation. When adding polygon, click right button to finish drawing.
- There are 12 color bars in total. And you can choose to show or hide temperature objects.
- Users can set up the attributes of object, such as equipment materials, equipment distance, equipment name, max temperature and min temperature. And you can adjust the temperature range automatically or manually.
- Please save the operation after setting, and then click "quit".




Figure 35

b. IR Gas Image

After adding pictures, please click right mouse button and select "Attribute settings". The menu bar pops up, as shown in Picture 36.

- e. Switch the display between IR and Gas mode.
- f. The operations of image attributes are the same as IR Non-gas Image.
- g. UV images are not available for this function!




Figure 36

8.3.10. Audio Play

Select the pictures you added by the function of original picture, and click right mouse button. Then select "Play Audio". The play interface will pop up automatically. However, this function is merely available for the pictures with voice annotations.

8.3.11. List box

Select "List Box" in the tool bar, and add it into template. You can adjust row number and cow number upon you needs.




Figure 37

After addition, users can edit the table. For example, you can set up the appearance and font (refer to sec 8.3.4). However, cell merging is unavailable so that you have to splice tables by yourself. As shown in 38.

Rransformer Substation	XXX	Weather	XXX
Device Name_Position	XXX	Device History Max Current(A)	1540
Rating Current(A)	3150	Load Current(A)	1435
GPS N		GPS E	

Figure 38

Users can change the display information when you select one certain cell, click right mouse button and select "Cell Properties". As shown in figure 39.




Figure 39

8.3.12. Vertical list

Select “Vertical list” in tool bar, add it into template, click right mouse button and choose “Picture Attribute”. Users can add picture information and message object, as well as change the original picture number. As shown in figure 40.




Figure 40

8.3.13. Line Analysis

In order to use this function, users have to add lines to the added pictures in “Image Setup” beforehand.

Select “Line Analysis” in tool bar, click right mouse button and choose “Attribute Settings”. Then the menu bar pops up, as shown in figure 41. According to needs, users can check grid line, legend and lines. As shown in figure 42.




Figure 41




Figure 42

8.3.14. Histogram

This function aims to display the line analysis in histogram. And users also need to add lines to the added pictures in "Image Setup" beforehand.

Select "Histogram" in tool bar, click right mouse button and choose "Attribute Settings". Then the menu bar pops up, as shown in figure 43. Users can choose the picture, measuring line, histogram number and colour. And you can add grind line according to needs.

There is an example in the figure 44.




Figure 43




Figure 44

8.3.15. Page Attribute

Click right mouse button at the blank of the template, and select the option “Page”. Here, the page attribute can be set up to “Cover Page”, “Head Page”, “Content Page” and so on.

If all pages are “Content Page”, users can add any number of pages, or any number of pictures on the same page. If one of the pages are not “Content Page”, then users can only add one page of “Content Page” which just has one single picture.




Figure 45

8.3.16. Video Transmission

a. Preparation: USB Driver Installation of C-type Win10

If users prefer connecting device to PC by USB, you'd confirm that you have installed the USB driver files firstly! For some devices, USB driver files need to be installed manually!

There are the installation steps.

Firstly, please click the win button. Then click “Settings”, and in this menu, please click “Update & security”. Here, select “Recovery”, and then click “Restart now” which is at the menu of “Advanced startup”.

Waiting for some seconds, a new interface will pop up automatically. Please select “Troubleshoot” here, and click “Startup settings”. Then click “Restart”. In the new interface, press 7 in the number keyboard to select “Disable driver signature enforcement”.


Thirdly, select “Set up → System setup” in the device, and then select “Video” in the “USB” option. And then connect the device with PC by USB wire.

After connecting and restarting, please open the “Device manager”, and then find the corresponding device here. Right-click it and select “Update Driver Software”, then click “Browse my computer for driver software”, and add the file folder of driver.

b. IR Device

Please connect the device to the PC firstly. There are two connecting ways.

The first one is to select “Setup → System Setup → USB”, and then select video as transmission mode. By this way, please confirm the condition of USB driver files.

Open the software, Select , and then the “video player” box will appear. As shown in figure 46 and 47.












Figure 46



Figure 47





Click  and users can reach the devices nearby. Click  to connect the device, and click  to disconnect.  the device box can help users to select the devices they need.

For IR devices, there are two types of devices. For one kind of device, it could merely be shown as USB instead of the

IP address in the device box. In this situation, the functions of ,  and  are unavailable. For another kind, the device box shows the IP address, and the functions of ,

W and **T** are available. Users can achieve auto focusing when you click **A**, and adjust far-focus or near-focus when you click **W** or **T**.

For Gas devices, **A**, **W** and **T** are unavailable as gas device don't have the function of auto focusing.

Click   to record videos or stop recording. Click  to take photos. Click  to set up the save path of videos and photos.

c. UV Device

Please connect the device to the PC firstly. There are two connecting ways.

The first one is to select “Setup → System Setup → USB”, and then select video as transmission mode. By this way, please confirm the condition of USB driver files.









Open the software, select , and then the “video player” box will appear. As shown in figure 48.



Figure 48

Click  and users can reach the devices nearby. Click  to connect the device, and click  to disconnect. **192.168.1.119** can help users to select the devices they need.

Click **A**, **W** or **T**, users can achieve auto focusing, far-focus or near-focus. Click   to record videos or stop recording. Click  to take photos. Click  to set up the save path of videos and photos. Click to adjust the gain and mode.

10. Other Information

10.1. Cleaning and Maintenance

The casing and accessories of the camera may be cleaned with a soft, damp cloth using dilute all-purpose detergents. Do not use any solvents or cleaning agents (powders, pastes, etc.) as they can damage or scratch the casing

Only clean the lens by compressed air or special tools.

The electronic circuits of the camera do not require adjustments, or maintenance.

When drying the camera and accessories do not exceed the maximum storage temperature: 60°C / 140°F .

10.2. Storage

When storing the camera observe the following:

- make sure that the camera is dry and is stored in a dry place
- if the device is to be stored for longer time remove the battery
- do not exceed the maximum storage temperature: 60°C / 140°F


10.3. Dismantling and Disposal

Disused and scrapped electric and electronic equipment should be disposed of safely and ecologically responsibly according to local regulations, i.e. it must not be placed with waste of another kind.

Scrap electronic equipment should be sent to a collection point in accordance with the law of waste electrical and electronic equipment.

Before the equipment is sent to a collection point do not dismantle or disassemble any part of the camera.

Observe local regulations concerning the disposal of electronic waste, packaging, and expired batteries.



10.4. Transport

Always carry the camera and accessories in its original packaging or carrying case. Never carry the camera loose as it may be damaged due to shock and vibration. It is recommended to remove the battery from the camera during transport.

11. Technical specifications

UV optical parameters:

Image	monochrome video
Corona image rendering	white, red, blue
Minimum UV sensitivity	$2.2 \times 10^{-18} \text{ W / cm}^2$
Minimum Discharge Detection	1 pC at 10 meters
Spectral Range.....	UV 240 - 280 nm
Field of view (HxW).....	5.5° x 4.0°
Focus	automatic or manual
Focus range.....	above 2 m
Detector life	no degradation
Frequency	50Hz

Visible optical parameters:

Image	true colour
Overlay accuracy for UV/visible radiation image.....	better than 1 milliradian
Minimum Sensitivity	0.1 lux
Zoom	25x optical and 12x digital

Display:

Type	5.7" VGA TFT, folding touch-screen
Video standard	PAL/NTSC selectable
Display Modes	Mixed (UV + visible) / UV only / Visible radiation only

Processing and Communication:

Video standard	H.264
Alarms	audio, LED
Operation.....	buttons and touch-screen
Audio module.....	Microphone input for voice notes, headphone output
GPS Module	built-in

Data Storage:

Memory Type.....	SD memory card
Image format	JPG
Video Format	AVI
Memory	8000 photos or up to 4 hours of video (for 2GB card)
File Transfer	USB, card reader

Power system:

Rechargeable	Li-Ion battery, dedicated
Power Consumption.....	10W
Charging.....	via power adapter, or external charger
Mains.....	power adapter 110 to 240V AC, 50/60Hz / 12V DC, 3.8A
Power supply from a car socket	9 to14V, 10VA
Battery operating time.....	about 2 hours

Other:

Degree of enclosure protection acc. to EN 60529.....	IP54
Operating temperature	-10°C to +50°C / 14°F to +122°F
Storage temperature	-25°C to +60°C / -13°F to +140°F
Humidity	100%..95%, non-condensing
Weight.....	2.5kg / 5.5 lbs
Dimensions.....	238 x 165 x 91 mm / 9.4 x 6.5 x 3.6 ins
Video Output.....	CVBS
Audio input / output.....	combined jack for microphone and headphones / headset

12. Accessories



Fig. 39 Standard accessories for UV-260.

Corona camera UV-260.....	1 pc.
Charger.....	1 pc.
Rechargeable battery.....	2 pcs
AC Adapter.....	1 pc.
Car adapter 12V.....	1 pc.
SD card min. 8GB.....	2 pcs
External SD card reader (USB).....	1 pc.
Headset with microphone.....	1 pc.
Strap.....	1 pc.
Transport case.....	1 pc.
Video cable.....	1 pc.
USB cable.....	1 pc.

13. Manufacturer

Camera manufacturer and provider of warranty and service:

SONEL S.A.

Wokulskiego 11
58-100 Świdnica
Poland

Tel: +48 74 858 38 60

Fax: +48 74 858 38 09

E-mail: export@sonel.pl

Web page: www.sonel.pl

NOTE

Service repairs must only be performed by the manufacturer.

NOTES



SONEL S.A.
Wokulskiego 11
58-100 Świdnica
Poland



+48 74 858 38 60
+48 74 858 38 00
fax +48 74 858 38 09

e-mail: export@sonel.pl
www.sonel.pl