

# MPI-507 / 506 /

index: WMGBMPI507 / WMGBMPI506 / WMGBMPI502F









# Great little multitasker

### **Features**

#### Measurement of short circuit loop parameters

- Measurement of short circuit loop impedance in networks with rated voltage: 220/380 V, 230 V/400 V, 240/415 V and frequency 45...65 Hz, operating voltage range: 180...460 V
- Indication of short circuit loop resistance R and short circuit loop reactance X
- Measurements of short circuit loop impedance with 15 mA current, without tripping the RCD circuit breaker
- Maximum test current: 7.6 A (at 230 V), 13.3 A (at 400 V)

#### Testing RCD breakers of AC, A types

- Testing of prompt, short-delay and selective RCDs with rated current values 10, 15, 30, 100, 300, 500 mA
- Measurement of  $I_A$  trip current and tripping time  $t_A$  for currents  $0.5 I_{\Delta n}$ ,  $1 I_{\Delta n}$ ,  $2 I_{\Delta n}$ ,  $5 I_{\Delta n}$
- R<sub>E</sub> and U<sub>R</sub> measurement without RCD tripping
- Extended AUTO function of RCD measurement, with the possibility of measuring  $Z_{\text{L-PE}}$  with low current • Measurement of  $I_{\text{A}}$  and  $I_{\text{A}}$  during one RCD tripping

### • MPI-507 | Earth resistance measurement

- Measurement with 3-pole method
- MPI-506 MPI-507 | Insulation resistance measurement
  - Test voltage 100 V, 250 V, 500 V

#### Measurement of resistance of protective conductors and equipotential bondings


- · Measurement of protective connections continuity with a ±200 mA current in accordance with EN 61557-4
- Autocalibration of test leads any leads can be used
- Low current resistance measurement with sound signaling
- MPI-506 MPI-507 | Phase sequence indication

### **Additional functions**

- Checking the correctness of PE connection using a contact electrode
- Measurement of voltage (0 ... 500 V) and network frequency
- Memory of 990 results
- Wireless data transmission to a computer
- Backlit keypad







## Simplicity and cutting edge technologies

Probably the **world's smallest meter** with such a large number of measurement functions. The functions are selected with a rotary switch. Additional parameters are set with buttons located on the housing face. The settings are saved by the device even when the battery is completely discharged.

All buttons and the modular display have backlight, which significantly improves operation in low light. Large memory eliminates the need for taking notes during the measurements.



## **Inspection of electrical safety**

This device may be used to inspect safety of electrical systems in households and industrial facilities. Its main advantage is **quick measurement (just a few seconds!) of fault loop impedance** in circuits with RCD.

Measurements can be easily automated with:

- auto mode of residual current devices (RCD) tests,
- the WS adapter that can be used for testing systems via standard 230 V sockets.



### MPI-507 | Earth resistance measurement

The device is ideal for measurements of earthing installations in residential buildings. It allows you to check the quality of the earthing system using the 3-pole method. Together with earth resistance result, the meter shows the interference voltage and the resistance of the auxiliary  $R_{\rm s}$  and  $R_{\rm H}$  probes.



### Increased resistance to environmental conditions

The meter will cope well in difficult environmental conditions. Protection against penetration of dust and water is ensured by a unique housing with a level of protection IP67.

### **Communication and software**

You can easily transfer measurement data to your computer via Bluetooth wireless communication. In order to generate a report on measurements for electric shock protection, use **Sonel Reports PLUS** software. Saving the downloaded data to the simplest formats and printing is provided by free **Sonel Reader** software.



page 2 / 4 sonel.com

Specifications  Measurement functions	Measurement range	Display range	Resolution	Accuracy ±(% m.v. + digits)	
Fault loop impedance	runge	range			
Fault loop $Z_{L-PE'}$ , $Z_{L-N'}$ , $Z_{L-L}$	0.13 Ω1999 Ω acc. to IEC 61557	0.00 Ω1999 Ω	from 0.01 Ω	±(5% m.v. + 3 digits)	
Fault loop Z <sub>L-PE</sub> in RCD mode	from 0.5 Ω1999 Ω acc. to IEC 61557	0.00 Ω1999 Ω	from 0.01 Ω	from ±(6% m.v. + 5 digits	
Measurements of RCD parameters					
RCD tripping test and measurement of tripping measuring current $0.5 I_{\Delta n'} 1 I_{\Delta n'} 2 I_{\Delta n'} 5 I_{\Delta n}$	ping time t <sub>A</sub>				
general and short-time delay RCD	0 ms300 ms	0 ms300 ms	1 ms	±(2% m.v. + 2 digits)	
selective RCD	0 ms500 ms	0 ms500 ms	1 ms	±(2% m.v. + 2 digits)	
Measurement of RCD tripping current $I_A$ measuring current 0.3 $I_{\Delta n}$ 2.0 $I_{\Delta n}$					
for sinusoidal residual current (AC type)	3.0 mA500 mA	3.0 mA500 mA	from 0.1 mA	±5% I <sub>∆n</sub>	
for unidirectional residual current and unidirectional with the 6 mA DC bias (type A)	3.5 mA420 mA	3.5 mA420 mA	from 0.1 mA	±10% I <sub>∆n</sub>	
MPI-507   Earth resistance					
3-pole method	0.68 Ω1999 Ω acc. to IEC 61557-5	0.00 Ω1999 Ω	from 0.01 Ω	from ±(3% m.v. + 5 digits	
MPI-506 • MPI-507   Insulation resistance					
Measuring voltage 100 V	100 kΩ99.9 MΩ acc. to IEC 61557-2	0 kΩ99.9 MΩ	from 1 kΩ	±(5% m.v. + 8 digits)	
Measuring voltage 250 V	250 kΩ199.9 MΩ acc. to IEC 61557-2	0 kΩ199.9 MΩ	from 1 kΩ	±(5% m.v. + 8 digits)	
Measuring voltage 500 V	500 kΩ599.9 MΩ acc. to IEC 61557-2	0 kΩ599.9 MΩ	from 1 kΩ	±(5% m.v. + 8 digits)	
Resistance of protective conductors and eq	uipotential bondings				
Measurement of resistance of protective	0.12 Ω400 Ω				
conductors and equipotential bondings with ±200 mA current	acc. to IEC 61557-4	0.00 Ω400 Ω	from 0.01 Ω	±(2% m.v. + 3 digits)	
Measurement of resistance with low current	0.0 Ω1999 Ω	0.0 Ω1999 Ω	from 0.1 $\Omega$	±(3% m.v. + 3 digits)	
MPI-506 • MPI-507   Phase sequence indication	in the same direction (correc	ct), opposite direction (inco	orrect), U <sub>L-L</sub> voltage: '	100 V440 V (45 Hz65 H:	
Safety and operating conditions					
Measuring category acc. to EN 61010		IV 300 V (III 600 V)			
Ingress protection			IP67		
Type of insulation acc. to EN 61010-1 and IEC 61557		double			
Dimensions		220 x 102 x 61 mm			
Weight	ca. 0.8 kg				
Memory and communication					
Memory	990 cells, 10 000 records				
Data transmission	Bluetooth				
Other data					
The product meets the EMC (emission for industrial environment) requirements according to standards		EN 61326-1 EN 61326-2-2			

page 3 / 4 sonel.com

### Standard accessories



WS-03 adapter with START button (UNI-Schuko plug)

WAADAWS03



Crocodile clip 1 kV 20 A red

only for: • MPI-506

• MPI-506 • MPI-507

WAKRORE20K02



Crocodile clip 1 kV 20 A yellow

WAKROYE20K02



Test lead 1.2 m (banana plugs) red / blue / yellow

WAPRZ1X2REBB WAPRZ1X2BUBB WAPRZ1X2YEBB



Test lead 30 m, red (banana plugs, on H-frame reel) only for MPI-507

WAPRZ030REBBN



Test lead 15 m, blue (banana plugs, on H-frame reel) only for MPI-507

WAPRZ015BUBBN



Pin probe 1 kV (banana socket) red / blue

WASONREOGB1 WASONBUOGB1



Pin probe 1 kV (banana socket) yellow

only for: • MPI-506 • MPI-507

WASONYEOGB1



2 x earth contact test probe (rod), 25 cm only for MPI-507

WASONG25



M1 hanging straps

M1 hanging hook straps WAPOZUCH1



M6 carrying case

WAFUTM6



4 x LR6 1.5 V battery

Factory calibration certificate

# **Optional accessories**



EVSE-01 adapter for testing vehicle charging stations

WAADAEVSE01



TWR-1J RCD breaker testing adapter

WAADATWR1J



WS-04 adapter (UNI-SCHUKO angular plug)

WAADAWS04



Test lead for fault loop measurement (banana plugs) 5 m / 10 m / 20 m

WAPRZ005REBB WAPRZ010REBB WAPRZ020REBB



Foldable pin probe, 1 kV, 2 m (banana socket)

WASONSP2M



Crocodile clip 1 kV 20 A blue

WAKROBU20K02





Industrial socket adapter 16 A / 32 A

WAADAAGT16T WAADAAGT32T





Three-phase socket adapter 16 A / 32 A

WAADAAGT16C WAADAAGT32C



Three-phase socket adapter 16 A / 32 A

WAADAAGT16P WAADAAGT32P



Three-phase socket adapter 63 A

WAADAAGT63P



Sonel Reports PLUS software



Calibration certificate with accreditation

page 4 / 4

sonel.com